



CLEANING & MAINTENANCE INSTRUCTIONS FOR LAMINATE VANITY UNITS

ESSENTIAL MATERIALS

- Paper towel
- Soft cloths
- Sponges
- Non-abrasive detergents
- Water

CLEANING LAMINATE VANITY UNIT

Always start by trying the gentles method of cleaning. If a stain persists, workthrough the following steps, repeat each step several times if the stain seems to be disappearing.

STEP 1

For routine cleaning, such as dust or liquid, to remove the stain by scrubbing the area with a soft cloth, dampened with room temperature or warm water. Rinse and dry with a paper towel or soft cloth.

STEP 2

If the stain leaves a slight mark or is difficult to remove, repeat the cleaning operation using mild detergents.

STEP 3

If the stain is stubborn, treat it with a suitable detergent solution. Allow the detergent to act long enough to remove the stain. Remove the detergent using a dampened sponge. Dry with a paper towel or soft cloth. If the stain is still visible, repeat this procedure or use a more detergent to be effective.

STEP 4

When cleaning the difficult stain from the laminate, DO NOT expose the material surface to household bleach for prolonged periods of time as this may lead to permanent discolouration.



DO AND DO NOT

DO always rinse thoroughly after cleaning (residue from cleaning solutions is the single greatest cause of damage to laminate surfaces).

Do wipe up spills immediately, and rinse thoroughly.

DO NOT use acidic or abrasive cleaners, expose the laminate to household bleach for prolonged periods of time, or apply excessive scrubbing, especially on gloss finish surfaces.

REMOVING ACCESS UNDER-PANELS (WHERE APPLICABLE)

Access panels and vanity unit under-panels are normally fitted using nylon Keku hook and peg fixings. To release a panel, it must be lifted vertically by 20mm in order for the hook to release from the peg. The panel should be handled using a glass suction pad. Please don't lever the panel using screwdrivers as this will inevitably damage the panel clippings.

GENERAL NOTES

In order to avoid watermarks/ limescale buildup, standing water should be removed from horizontal surfaces. Any water that splashes onto a panel edge should be removed immediately.

Ensure the vanity unit is correctly sealed using silicone or similar product. Failure to correctly seal the vanity unit may allow water ingress, leading to failure at laminate joints.



1 Northern Way
Bury St Edmunds
Suffolk
IP32 6NH

(+44) 01284 727626 | sales@helmsman.co.uk | www.helmsman.co.uk